

LENNTECH

info@lenntech.com Tel. +31-152-610-900 www.lenntech.com Fax. +31-152-616-289

FILMTEC Membranes

System Design: System Performance Projection

Design Equations and Parameters

The performance of a specified RO system is defined by its feed pressure (or permeate flow, if the feed pressure is specified) and its salt passage. In its simplest terms, the permeate flow Q through an RO membrane is directly proportional to the wetted surface area S multiplied by the net driving pressure $(\Delta P - \Delta \pi)$. The proportionality constant is the membrane permeability coefficient or A-value. The familiar water permeation equation has the form:

$$Q = (A)(S)(\Delta P - \Delta \pi)$$
 Eq. 8

The salt passage is by diffusion, hence the salt flux N_A is proportional to the salt concentration difference between both sides of the membrane. The proportionality constant is the salt diffusion coefficient or B-value.

$$N_A = B(C_{fc} - C_{p})$$
 Eq. 9

where:

C_{fc} = feed-concentrate average concentration

 C_p = permeate concentration

There are basically two ways to calculate the performance of a specified design: "Element-to-Element" and "Entire System".

Element-to-Element

This is the most rigorous calculation method. It is too tedious for hand calculation, but it is suitable for computer calculations. All the operating conditions of the first element must be known, including the feed pressure. Then the flow, pressure, etc., of the concentrate, which is the feed to the second element, can be calculated. After calculating the results for all the elements, the original feed pressure may be too high or low, so the trial and error process starts with a new pressure.

With the help of the FILMTEC™ Reverse Osmosis System Analysis (ROSA) computer program, accurate results can be obtained very quickly, so this program can be used to modify and optimize the design of an RO or an NF system. Accordingly, the entire system calculation method will not be described here. It is also not intended to outline the process of the element to element computer calculation. However, the governing equations and parameters are given in Table 3.9.

In order to enable the determination of values for the terms A, ΔP , and $\Delta \pi$ in Eq. 8, the water permeation equation is expanded to Eq. 10. The permeate concentration can be derived from Eq. 9 after conversion into Eq. 19. The design equations are listed in Table 3.9, the symbol definitions in Table 3.11.

Design Equations and Parameters (cont.)

The subscript /in the equations of Table 3.9 indicates that they apply to the /th element in a sequence of n elements in a series flow configuration. To accurately determine system performance, Eq. 10 is successively solved for each of the n elements starting with an inlet set of conditions. The solutions depend on mass balances around each element for salt (Eq. 14) and water (Eq. 19), as well as correlations for individual element parameters such as concentrate-side flow resistance, ΔP_{fc} (Eq. 27c); temperature correction factor for water permeability, TCF (Eq. 16); polarization factor, pf; (Eq. 17), and the membrane permeability coefficient for water, $A_i(\pi_i)$ (Eq. 28) which in the case of the FILMTEC FT30 membrane depends on the average concentrate concentration or, alternatively, osmotic pressure. These solutions usually involve a suitable average for the feed and permeate side hydraulic and osmotic pressures. For low recovery values typical of single element operation, an accurate solution can be obtained using a simple arithmetic average of the inlet and outlet conditions. Even so, since the outlet conditions are not known, iterative trial and error solutions are involved.

Table 3.9 Design equations for projecting RO system performance: individual element performance

Item	Equation	Equation Number
Permeate flow	$Q_{i} = A_{i}\overline{\pi}_{i}S_{E}(TCF)(FF)\left(P_{fi} - \frac{\Delta P_{fc_{i}}}{2} - P_{pi} - \overline{\pi} + \pi_{pi}\right)$	10
Average concentrate-side osmotic pressure	$\overline{\pi}_i = \pi_{fi} \left(\frac{C_{fc_i}}{C_{f_i}} \right) (pf_i)$	11
Average permeate-side osmotic pressure	$\overline{\pi}_{\rho i} = \pi_{fi} (1 - R_i)$	12
Ratio: arithmetic average concentrate-side to feed concentration for Element /	$\frac{C_{fci}}{C_{fi}} = \frac{1}{2} \left(1 + \frac{C_{ci}}{C_{fi}} \right)$	13
Ratio: concentrate to feed concentration for Element /	$\frac{C_{c_i}}{C_{f_i}} = \frac{1 - Y_i (1 - R_i)}{(1 - Y_i)}$	14
Feed water osmotic pressure	$\pi_f = 1.12(273 + T) \sum m_j$	15
Temperature correction factor for RO and NF membrane	TCF = EXP $\left[2640\left(\frac{1}{298} - \frac{1}{273 + T}\right)\right]$; T $\geq 25^{\circ}$ C	16a,b
	TCF = EXP $\left[3020 \left(\frac{1}{298} - \frac{1}{273 + T} \right) \right]$; T \le 25°C	
Concentration polarization factor for FILMTEC 8-inch elements	$pf_i = \text{EXP}[0.7Y_i]$	17
System recovery	$Y = 1 - [(1 - Y_1)(1 - Y_2)(1 - Y_n)] = 1 - \prod_{i=1}^{n} (1 - Y_i)$	18
Permeate concentration	$C_{p_j} = B(C_{fc_j})(pf_i)(TCF)\frac{S_E}{Q_i}$	19

Design Equations and Parameters (cont.)

Entire System

Average values are used to calculate feed pressure and permeate quality if the feed quality, temperature, permeate flow rate and number of elements are known. If the feed pressure is specified instead of the number of elements, the number of elements can be calculated with a few iterations. The design equations for 8-inch BW30 FILMTEC elements are listed in Table 3.10, the symbol definitions in Table 3.11.

Table 3.10 Design equations for projecting RO system performance: system average performace

Item	Equation	Equation Number
Total permeate flow	$Q = N_E S_E \overline{A} \overline{\pi} (TCF) (FF) P_f - \frac{\overline{\Delta P}_{fc}}{2} P_\rho - \pi_f \left[\frac{\overline{C}_{fc}}{C_f} p_f - (\overline{1} - \overline{R}) \right]$	20
Ratio: average concentrate- side to feed concentration for system	$\frac{C_{fc}}{C_f} = \frac{-\overline{R}\ln(1-Y/Y_L)}{Y-(1-Y_L)\ln(1-Y/Y_L)} + (1-\overline{R})$	
Limiting system recovery	$Y_{L} = 1 - \frac{\pi_{f}(\overline{pf})(\overline{R})}{P_{f} - \Delta P_{fc} - P_{p}}$	22
Approximate log-mean concentrate-side to feed concentration ratio for system	$\left. \frac{C_{fc}}{C_f} \right _{Y_L, \overline{R} = 1} = -\frac{\ln(1 - Y)}{Y}$	23
Average element recovery	$Y_i = 1 - \left(1 - Y\right)^{1/n}$	24
Average polarization factor	$\overline{pf} = EXP[0.7\overline{Y_i}]$	25
Average concentrate-side osmotic pressure for system	$\overline{\pi} = \pi_i \left(\frac{\overline{C}_{fc}}{C_f} \right) \overline{\rho f}$	26
Average concentrate-side system pressure drop for FILMTEC 8-inch elements; 2 stages	$\overline{\Delta P}_{fc} = 0.04 \overline{q}_{fc}^{2}$ $\Delta P_{fc} = \left[\frac{0.1 (Q/1440)}{Y N_{V2}} \right] \left(\frac{1}{N_{VR}} + 1 - Y \right)$	27a,b,c
Individual FILMTEC 8-inch element, or single-stage concentrate-side pressure drop	$\Delta P_{fc} = 0.01 n \overline{q}_{fc}^{1.7}$	
FILMTEC membrane permeability as a function of	$\overline{A}(\overline{\pi}) = 0.125; \overline{\pi} \le 25$	28a,b,c
average concentrate-side osmotic pressure	$\overline{A}(\overline{\pi}) = 0.125 - 0.011\left(\frac{\overline{\pi} - 25}{35}\right); 25 \le \overline{\pi} \le 200$	
	$\overline{A}(\overline{\pi}) = 0.070 - 0.0001(\overline{\pi} - 200); 200 \le \overline{\pi} \le 400$	
Permeate concentration	$C_p = BC_{fc} \overline{pf} (TCF) \left(\frac{N_E S_E}{Q} \right)$	29

Design Equations and Parameters

Table 3.11 Symbol definitions

(cont.)

Q _i	permeate flow of Element / (gpd)	\sum_{j}	summation of all ionic species
$A_i\pi_i$	membrane permeability at 25° for Element <i>i</i> , a function of the average concentrate-side osmotic pressure (gfd/psi)	Y	system recovery (expressed as a fraction) = permeate flow/feed flow
S _E	membrane surface area per element (ft²)	$\prod_{i=1}^{n}$	multiplication of n terms in a series
TCF	temperature correction factor for membrane permeability	n	number of elements in series
FF	membrane fouling factor	Q	system permeate flow (gpd)
P_{fi}	feed pressure of Element /(psi)	N _E	number of elements in system
ΔP_{fci}	concentrate-side pressure drop for Element / (psi)	\overline{Q}_i	average element permeate flow (gpd) = Q/N _E
P_{p_i}	permeate pressure of Element i (psi)	$\overline{A}\pi$	average membrane permeability at 25°C: a function of the average concentrate-side osmotic pressure (gfd/psi)
$\overline{\pi}_i$	average concentrate-side osmotic pressure (psi)	\overline{C}_{fc}	average concentrate-side concentration for system (ppm)
π_{fi}	feed osmotic pressure of Element i	R	average fractional salt rejection for system
π_{p_i}	permeate-side osmotic pressure of Element /(psi)	$\overline{\pi}$	average concentrate-side osmotic pressure for system (psi)
pf _i	concentration polarization factor for Element i	$\Delta \overline{P}_{fc}$	average concentrate-side system pressure drop (psi)
R _i	salt rejection fraction for Element / = $\frac{\text{feed conc perm. conc.}}{\text{feed conc.}}$	Y _L	limiting (maximum) system recovery (expressed as a fraction)
C _{fci}	average concentrate-side concentration for Element /(ppm)	\overline{Y}_i	average element recovery (expressed as a fraction)
C_{fi}	feed concentration for Element /(ppm)	pf	average concentration polarization factor
C _{ci}	concentrate concentration for Element / (ppm)	$\overline{q}_{\mathit{fc}}$	arithmetic average concentrate-side flow rate (gpm) (=1/2(feed flow + concentrate flow)
Y _i	recovery fraction for Element <i>i</i> $= \frac{\text{permeate flow}}{\text{feed flow}}$	N _V	number of six-element pressure vessels in system (\approx N _E /6)
π_f	treated feed water osmotic pressure (psi)	N_{V1}	number of pressure vessels in first stage of 2-stage system (\approx 1/3 Nv)
Т	feed water temperature (°C)	N _{V2}	number of pressure vessels in second stage of 2-stage system (≈ Nv/3)
m_j	molal concentration of jth ion species	N_{VR}	stage ratio (=N _{VI} /N _{V2})

Notice: The use of this product in and of itself does not necessarily guarantee the removal of cysts and pathogens from water. Effective cyst and pathogen reduction is dependent on the complete system design and on the operation and maintenance of the system.

Notice: No freedom from any patent owned by Seller or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, Customer is responsible for determining whether products and the information in this document are appropriate for Customer's use and for ensuring that Customer's workplace and disposal practices are in compliance with applicable laws and other governmental enactments. Seller assumes no obligation or liability for the information in this document. NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.

