

LENNTECH

info@lenntech.com Tel. +31-152-610-900 www.lenntech.com Fax. +31-152-616-289

FILMTEC Membranes

Troubleshooting: Symptoms of Trouble, Causes and Corrective Measures

Troubleshooting
GridChanges of the permeate flow, the salt passage and the differential pressure are symptoms
which can be attached to specific causes in many cases. Although, the symptoms of
different causes may over-lap in reality, and the symptoms are more or less pronounced in
specific cases. An overview of symptoms, their possible causes and corrective measures
are given in the troubleshooting grid of Table 8.1.

(An interactive troubleshooting guide with direct links to cleaning and remediation methods is available from the Dow Liquid Separations website under Technical Service Center -) http://www.lenntech.com/membrane-cleaning.htm

| Permeate flow | Salt passage | Differential pressure | Direct cause | Indirect cause | Corrective measure |
|------------------|-----------------|-----------------------|----------------------|---|---|
| ↑ | ſ | \rightarrow | Oxidation damage | Free chlorine, ozone, KMnO4 | Replace element |
| ↑ | ſ | \rightarrow | Membrane leak | Permeate backpressure; abrasion | Replace element, improve cartridge filtration |
| \uparrow | ↑ | \rightarrow | O-ring leak | Improper installation | Replace o-ring |
| \uparrow | ſ | \rightarrow | Leaking product tube | Damaged during element loading | Replace element |
| \downarrow | ↑ | \uparrow | Scaling | Insufficient scale control | Cleaning, scale control |
| \downarrow | ↑ | \uparrow | Colloidal fouling | Insufficient pretreatment | Cleaning, improve pretreatment |
| Ļ | \rightarrow | î | Biofouling | Contaminated raw water, insufficient pretreatment | Cleaning, disinfection, improve pretreatment |
| Ų | \rightarrow | \rightarrow | Organic fouling | Oil; cationic polyelectrolytes water hammer | Cleaning, improve pretreatment |
| \downarrow | \downarrow | \rightarrow | Compaction | Water hammer | Replace element or add elements |

Table 8.1 Symptoms, causes and corrective measures

↑ Increasing \downarrow Decreasing \rightarrow Not changing \uparrow Main symptom

LENNTECH info@lenntech.com Tel. +31-152-610-900 www.lenntech.com Fax. +31-152-616-289

Notice: The use of this product in and of itself does not necessarily guarantee the removal of cysts and pathogens from water. Effective cyst and pathogen reduction is dependent on the complete system design and on the operation and maintenance of the system.

Notice: No freedom from any patent owned by Seller or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, Customer is responsible for determining whether products and the information in this document are appropriate for Customer's use and for ensuring that Customer's workplace and disposal practices are in compliance with applicable laws and other governmental enactments. Seller assumes no obligation or liability for the information in this document. NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.

