


ABCOR[®] - INDUCOR[™]-G MODULE: 10-HFM-251-ICV

Industrial Multitubular Ultrafiltration Module

PRODUCT DESCRIPTION	Membrane Chemistry: Membrane Type: Membrane Area: Molecular Weight Cut-Off: Construction: Face Plate:			0712501 PVDF HFM (neutral charge) 15.4 ft ² (1.4 m ²) 100,000 Dalton (nominal) Seven (7) 1" diameter tubules in a PVC shell ABS VITON [®]			
OPERATING AND DESIGN INFORMATION*	Maximum Inlet Pressure: Maximum Operating Temperature: Maximum Permeate Side Back Pressure: Minimum Outlet Pressure: Maximum Feed Side Pressure Drop: Allowable pH - Continuous Exposure: Allowable pH - Short Term Exposure: * Consult KMS Industrial Process Technology Group for specific applied				90 psi @ 119 °F (6.2 bar @ 48 °C) 122°F (50 °C) at 84 psi max 3 psi (0.2 bar) 5 psi (0.3 bar) 6.6 psi @ 119 °F (0.4 bar @ 48 °C) 2.0 – 10.0 @ 119 °F (48°C) 1.5 – 10.5 @ 119 °F (48°C)		
FEED FLOW VS. PRESSURE	Circulation Flow gpm m ³ /hr		Cros f/s	ssflow Velocity m/s	Pressu psi	Pressure Drop psi bar	
DROP*	133 210 266	30 48 60	7.8 12.3 15.5	2.4 3.7 4.7	2.0 4.3 6.0	0.14 0.29 0.41	
	* Data based on water at 77° F and specific gravity of 1.0.						




ANCILLARY PARTS

KMS recommends that these membranes be used with KMS supplied ancillary parts. Sealing is provided by o-rings and gaskets. No additional sealing compound or tape is recommended for use on threaded connections.

INDUCORTM-G Module Process Pass Kits

One Process Pass Kit contains; Two Permeate Port Saddle Assemblies Two 4" Coupling Assemblies

Available in two styles of Permeate Port Saddle: 1" IPS Socket Style Pass Kit KPN 0211875 1" FNPT Threaded Style Pass Kit KPN 0211885



Permeate Port Saddle Assembly *I" IPS Socket Style KPN 0020616 I" FNPT Threaded Style KPN 0020618* (Each assembly contains all the needed fastening hardware and one Viton® o-ring) **Module Assembly 4" Coupling Assembly KPN 0125575** (Each assembly contains all the needed fastening hardware and one Viton® seal) **4" Process U-Bend** KPN 0020614

MEMBRANE INCOMPATIBILITY

Prior to exposing the membrane to any chemical, the chemical should be reviewed by Koch Membrane Systems. Aside from the listed chemicals below, synthetic coolants, semi-synthetic coolants, kerosenes, naphtha, gasoline, floc polymers may affect membrane performance.

Chemicals that should be avoided include the following:

- Aprotic Solvent (e.g., Dimethyl Formamide, Dimethyl Acetamide, N-Methyl Pyrolidine, etc.)
- Chlorinated Solvents (e.g., Methylene Chloride, Chloroform, Carbon Tetrachloride, etc.)
- Ketones (e.g., Acetone, Diacetone Alcohol, etc.)
- Silicones or Silicone based Defoamers (e.g., Siloxane)

The information contained in this publication is believed to be accurate and reliable, but is not to be construed as implying any warranty or guarantee of performance. We assume no responsibility, obligation or liability for results obtained or damages incurred through the application of the information contained herein. Refer to Standard Terms and Conditions of Sale for additional information.

LENNTECH info@lenntech.com Tel. +31-152-610-900 www.lenntech.com Fax. +31-152-616-289