

102. Recommended spare parts: SE, SL 9-30 kW

50/60 Hz


Customer Information

Project title:	Customer name:
Reference number:	Customer number:
Customer contact:	Customer phone number: ()
	Fax number: ()

Pump information

Quotation made by

Type		Prod. No.	
P.c.	∅ mm	No.	
▽	T °C	IP	Insul. class:
Model	Pol	Hz	V
P./P ₂	kW	I _N	A _{Start} A _N /min
Cos φ		Weight	kg
Ex			


 CH-6105 Schachen

Company name:

Prepared by:

Phone number: ()

Fax number: ()

Date:

Quote number:

Recommended spare parts

Kit - Spare - Bulk	Recommended service parts						Product number
	1 pump		2 to 3 pumps		4 to 7 pumps		
	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	
Kit, Shaft seal	1	2	2	3	4	8	
Kit, O-ring	1	2	2	3	4	8	
Kit, Impeller fixing	0	1	0	2	0	4	
Kit, Impeller	0	1	0	2	0	4	
Kit, Bearing	0	1	0	2	0	4	
Kit, Moisture switch	0	1	0	2	0	4	
Kit, plug	0	1	0	2	0	4	
Liquid for sub. Motor*	0	1	0	2	0	4	

* See service instruction for amount and type.

Above recommendations are based on:

Agitators running in normal operation should be checked every 3000 operating hours or at least once a year.

If the stirred liquid is very muddy or sandy, check the pump at shorter intervals.